Meter Reading Instructions

SF_	750-thru-781 7100-thru-7900 8100-thru-8875 9400-thru-9800 1420-thru-1430 2014-thru-2530	Hold Down 0 (zero) key for more than 5 seconds. Display will show meter two digits at a time. If this does not work perform the following. Press Clear ©, Interrupt, Zero (0) Interrupt, 2, 2,Start, 5, Start. Meter should show on display. When done press clear all (CA).
AR_	160-207	
AR_	150-157EN	Hold down Clear © button for more than 10 Seconds.
AR_	280-thru-507	Press Program, Interrupt, Clear ©, Interrupt, 2, 2, Start, 1, Start. Total counter will be on display. Press Clear All (CA) when done. If this doesn't work press COPY key.
ARC_	150-270	
ARM_	280-700	Press Program, Asterisk (*), Clear ©, Asterisk (*), 2, 2, Start, 1, Start. Total counter will be on display. Press Clear All (CA) when done. If this doesn't work press COPY key.
AR_	650-810	Mechanical counter on Operation Panel
AR_	BC260-320	Press Program(#/P), Asterisk (*), Clear ©, Asterisk (*), 2, 2, Black and White Start, 1, Black and White Start. If this doesn't work press the COPY key.
AR_	168	Press Clear ©, Exposure Adjust, Clear ©, Exposure Adjust, use arrow key to put 22 in display, Start, 5, Start.

IT IS IMPORTANT , IF YOUR MACHINE IS NETWORKED TO PRINT, MAKE SURE TO TURN IN ALL READS MACHINE GIVES.